



WOOD FINISHES DIRECT

The following Technical Datasheet is provided by **Bona**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:
[Bona Stone, Tile and Laminate Floor Spray Mop](#)

Bona Spray Mop

Technical data sheet

Bona Spray Mop for Tile & Laminate floors enables you to clean and maintain your floors in a sweep. Ergonomic and simple to use, the Spray Mop is quick to assemble and refill with the specially developed Bona Tile & Laminate cleaner. Forget filling up a bucket and adding concentrate, just spray and clean! You can use Tile & Laminate cleaner on tile, laminate, and other hard surfaces such as ceramic, linoleum, vinyl, granite and more.

- Specially developed for Tile and Laminate floors
- Environmentally sound, pH neutral cleaner
- Refillable cleaner cartridge
- Ergonomic mop design
- Rotating head for ultimate reach in difficult areas
- Washable Microfiber cleaning pad

Content

- Spray Mop
- Refillable Tile & Laminate Cleaner Cartridge (0,85 litre)
- Microfiber Cleaning Pad, washable up to 300 times

Preparations

Vacuum floors before wet cleaning to ensure that dirt and grit is removed to prevent any scratching on your floors.

Sold separately

- 4L Tile & Laminate Cleaner Refill
- 0,85L Tile & Laminate Cleaner cartridge
- 0,85L Wood Floor Cleaner cartridge
- Microfiber Cleaning Pad

Directions for use

Insert Tile & Laminate Cleaner cartridge into Spray Mop. Press it firmly into its socket. Attach the cleaning pad on the mop head. Mist cleaner onto floor and wipe clean. On stubborn spots, rubber heel marks or sticky spills spray cleaner directly onto spot and let work a few minutes before scrubbing and wiping off.

Soiled cleaning pads should be washed in 60°C without fabric softener.



Bona[®]
Passion for wood floors