

The following Product Datasheet is provided by Liberon

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit: Liberon Home ColourCare Decorative Furniture Wax



Colourcare DECORATIVE FURNITURE WAX



Format: 500 ml

Metallic and Pearlised finish

- Natural wax formula
- Resistant to stains and water
- Available in 8 colours

Home ColourCare DECORATIVE FURNITURE Wax is formulated with natural waxes and pearlised pigments, and gives a silky sheen with iridescent reflections. It nourishes wood and offers resistance to everyday stains (water, etc.). It does not clog up wood or show fingerprints and is not sticky. For all wood types: do a patch test first. The clear version can be used to maintain waxed furniture.

APPLICATION: Brush and cloth DRYING TIME: 2H recoat COVERAGE: 500ML = 8m² TOOL CLEANING: Water

INSTRUCTIONS

Apply to bare, coloured or waxed wood.

1. Using a brush, apply Decorative Furniture Wax in the direction of the grain.

2. Wipe off any excess immediately afterwards and spread out evenly with a cotton cloth. Leave to dry for 2 hours.

3. Buff with Liberon Furniture Brush or a woollen cloth to create a silky finish. Apply a second coat for a longer-lasting result.

For a more striking effect: do not wipe away the wax.

LIBERON TIPS AND ADVICE

The effect will be more marked on wood with a prominent grain or previously brushed wood. Before applying the wax, you can open the pores in the wood using Liberon Liming Bronze Brush.

The effect will be more uniform on finely sanded wood. If you're not satisfied with the result: before the wax is dry, remove with a damp sponge and start again.

HEALTH AND SAFETY

This product should be used in accordance with the manufacturer's instructions. Recommendations are for guidance only since conditions of use are completely beyond our control.

DO NOT ALLOW TO FREEZE

EUH208: Contains 2-methyl-2H-isothiazole-3-one and 1,2-benzisothiazol-3(2H)-one. May produce an allergic reaction. P102: Keep out of reach of children. P271: Use only outdoors or in a well-ventilated area. P501: Dispose of contents / container at a waste collection centre (contact the local authority).