

The following Product Datasheet is provided by **Liberon**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit: Liberon Black Patinating Wax



Black Patinating Wax

- Special effects wax
- Ages modern furniture
- Disguises repairs to old and new furniture
- Fakes grime on picture frame
- Suitable for use on wood, metal, gilt, plaster, tone, MDF and papier maché



USAGE

Decorative Interior

COVERAGE

250 ml 2-3 m² APPLICATION

Brush, Cloth or Steel Wool DRYING TIME

5 minutes

TOOL CLEANING

White Spirit

Product use

Liberon Black Patinating Wax creates striking effects on all types of material such as metal, wood and plaster. It is ideal for ageing modern furniture and disguising repairs to old and new furniture. It can also be used for adding a coloured finish or highlighting areas on finished pieces such as carvings.

Preparation

Ensure the surface is clean, dry and free from any previous finishing materials.

Application

Wipe onto the surface with a cloth or brush and allow to dry for 2-3 minutes before removing as much or as little of the excess as you wish with a clean lint-free cloth or Liberon Ultra Fine Steel Wool (0000).

To use the wax as a coloured finish on bare wood, work a thin coat into the wood with Ultra Fine Steel Wool (0000), allow to become touch dry and buff.

Once dry the wax may be sealed with Liberon White Polish.

To remove large areas of Special Effect Wax use Liberon Wax Polish Black Bison Neutral and buff. For a water resistant finish use Liberon Finishing Oil applied with a lint-free cloth or Ultra Fine Steel Wool (0000).

Important: Always test product on a spare surface or inconspicuous area for colour compatibility and end result.

Colour

Jet Black

Packaging

Black Patinating Wax is available in 250 ml containers.

Heath and Safety

Harmful. Flammable. May cause sensitisation by skin contact. Repeated exposure may cause skin dryness or cracking. Keep out of the reach of children. Avoid contact with skin. Do not empty into drains. Wear suitable gloves. Use only in well-ventilated areas. If swallowed, do not induce vomiting: seek medical advice immediately and show this container of label. Contains silice, suitable respiratory equipment is recommended when using sand paper on dry surfaces.